

Flowchart – Managing Contaminated Material during Ground Penetration and Excavation

This flowchart has been developed to support implementation of TasPorts’ *Environmental Guideline - Managing Contaminated Material during Ground Penetration and Excavation*.

NOTE: TYPICAL TIMEFRAME: ALLOW 6 – 10 WEEKS

